# Natural finish interior varnish

- Maintains the natural look and feel of the wood
- Highly resistant to scratches and stains
- Water based, low VOC
- **Quick drying**
- European eco-label







**USAGE** 

Interior

COVERAGE 11

10-12 m<sup>2</sup>

**APPLICATION** 

Brush or sprav

DRYING TIME

Min 2 hours

TOOL CLEANING

Water



LIBERON

Natural Finish

INTERIOR

## **Product use**

Liberon Natural Finish Interior Varnish is a hardwearing and long-lasting varnish which is ideal for use on soft or hardwood furniture and most interior woodwork; such as skirting boards, doors, work surfaces and panelling. Keeping the natural feel and look of the timber Natural Finish Interior Varnish uses a non-yellowing and quick drying formula.

## **Preparation**

Sand the wood if required and remove all previous finishes. Ensure the surface is clean, dry and free from dust. If you want to colour the wood you can apply Liberon Palette Wood Dye to the timber before varnishing. Alternatively Liberon Palette Wood Dye may be added to the varnish to create unique colour tones. Liberon Palette Wood Dye is available in a range of wood shades.

# **Application**

Shake / stir well before use. Apply a reasonable coat of varnish evenly using a paint brush or short hair roller and allow to dry for a minimum of 2 hours before applying further coats. We recommend a minimum of 3 coats are applied, sanding lightly between coats if required. More coats may be required for items which are in heavy use. Allow the final coat of varnish a minimum of 24 hours drying time before use.

## **Important**

Always test product on a spare surface or inconspicuous area for colour, compatibility and end result.

## Cleaning and maintenance

Wipe any spills immediately. For general maintenance wipe over with a damp cloth using a mild detergent if required. If the surface shows signs of wear re-apply a coat of varnish.

## **Precautions**

- Allow all wood dyes to dry for a minimum of 8 hours before applying Natural Finish Interior Varnish.
- Care must be taken on the application of the first coat of Natural Finish Interior Varnish when being used over Liberon Palette Wood Dye. Keep brush strokes to a minimum as over brushing may lift out the colour.
- The varnish may raise the grain on some hard woods.
- Do not exceed a 20% dilution of Natural Finish Interior Varnish with Liberon Palette Wood Dye.
- Natural Finish Interior Varnish is not suitable for applying over an oil-based finish.

# **Health and Safety**

Keep out of the reach of children. Do not empty into drains. Use only in well ventilated areas. Do not allow to freeze. EU limit value for Natural Finish Interior Varnish (CatA/i): 150 g/L (2007)/ 130 g/L (2010). Natural Finish Interior Varnish contains max 2 g/L VOC.

#### Liberon advice

In order to avoid bubbles forming on the surface of the varnish when using a roller we recommend the use of a short hair roller and that work is not carried out at temperatures above 25°C. Apply successive coats in a c riss-cross format (right to left then left to right) applying the final coat in the direction of the grain.

This product should be used in accordance with the manufacturer's instructions. Recommendations are for guidance only since conditions of use are completely beyond our control. For technical or practical information on this or other Liberon products please contact Liberon Technical Services on 01797 367555Liberon Limited, Mountfield Industrial Estate, New Romney, Kent TN28 8XU.Tel: 01797 367555 Fax: 01797 367575 <a href="www.liberon.co.uk">www.liberon.co.uk</a>. Liberon Ltd is a V33 Group Company