

PROFESSIONAL FLOOR POLISH

SPECIAL WOOD FLOORS

PRODUCT DESCRIPTION

- Blanchon PROFESSIONAL FLOOR POLISH is designed for use on floors, in particular parquet and other wood floors.
- PROFESSIONAL FLOOR POLISH has a creamy consistency and a high wax content, giving it a high polishing power.
- Available Finishes: natural, colourless.

SUBSTRATE PREPARATION

- Level old or new floors by sanding (see Appendix* for details on sanding floors).
- Thoroughly remove all traces of dust.
- The wood floor must be perfectly clean and dry with, in general, a moisture content of less than 10%. Consult the relevant DTU in force (*please contact our Export Department for further information on French building rules and specifications*). Do not use detergents or whiteners.
- PROFESSIONAL FLOOR POLISH can be applied over a coat of Blanchon PRIMER⁽¹⁾, which reduces the penetration of the PROFESSIONAL FLOOR POLISH and makes it easier to obtain a good shine.

DIRECTIONS FOR USE

- The consistency is creamy between 14 and 25°C.
- Below 14°C, PROFESSIONAL FLOOR POLISH sets and does not flow.
- Above 25°C, PROFESSIONAL FLOOR POLISH becomes liquid (when cooled, it thickens again).

APPLICATION

- This creamy consistency makes the polish very easy to apply. Proceed as follows:
- Pour the polish onto the floor. Only use in well ventilated areas. Do not leave plants and aquariums in contact with the solvent vapours.
- Spread evenly with a cotton cloth or a special brush.
- Leave to dry then polish with a light-coloured pad (beige or white) or woollen cloth. A good shine can be obtained quickly and easily with a buffing machine.
- Two coats are sometimes needed for a very high-quality durable finish.
- PROFESSIONAL FLOOR POLISH can be used in heated buffing machines with the thermostat set above 25°C.

CLEANING OF TOOLS

- Clean equipment immediately after use with Blanchon ODOURLESS THINNER or turpentine. Do not empty into drains.

DRYING TIMES

- Dust free: Around 4 to 6 hours, under normal conditions.
- Before polishing: Around 16 to 24 hours, under normal conditions.

NB: Good-quality polish should always be allowed to dry thoroughly before polishing, because a good shine cannot be obtained until the different waxes are completely dry.

(1) PREPLAST PRIMER, S.O. PRIMER

High polishing power



High hard wax content



Ideal for wood floors,
panelling and furniture

The logo for Blanchon, featuring the brand name in a white, stylized, cursive font on a dark blue rectangular background.

PROFESSIONAL FLOOR POLISH

COVERAGE

- 15 to 20 m² per litre, depending on the absorption of the wood.

STORAGE

- At least 1 year in the original unopened container.
- Properly seal the container after use.

MAINTENANCE

- Remove dust regularly with a vacuum cleaner.
- PROFESSIONAL FLOOR POLISH is self-maintaining.
- As soon as the floor loses its sheen, it can be restored with a buffing machine (fitted with a beige or white pad) or with a woollen cloth.
- Carry out this operation regularly with a few drops of PROFESSIONAL FLOOR POLISH to maintain floor protection and shine (do not wait until the wax is worn through).
- Do not allow water to stand on the polished wood floor.
- Treat small stains with N° 000 Steel Wool and apply more polish to the area.

TECHNICAL DATA

USE	POLISH FOR WOODEN FLOORS, PANELLING & WOODWORK
TYPE OF RESINS	Natural and synthetic waxes
SPECIFIC GRAVITY	Family I, class 5b
DENSITY	0.77 (at 20°C, as per N F T 30020)
REGULATORY INFORMATION	Refer to the relevant Material Safety Data Sheet (also available on www.blanchon.com or www.quickfds.com)

*APPENDIX: MACHINE SANDING OF PARQUET FLOORS

- Parquet floors should be sanded with a floor sander, an edge sanding machine for the edges and a scraper for the corners.
- The floor sander should be used in the direction of the light or, better still if possible, the direction of the wood grain.
- Work regularly over the surface, treating it in an identical manner.
- 1st run: Use rough grain (24, 30 or 36) to expose the bare surface and level it.
- 2nd run: Use medium grain (50 or 60) to make the surface even.
- 3rd run: Use fine grain (100 or 120) to obtain a good finish.
- Then go round the edges of the floor with an edge sanding machine and scraper.
- Polishing with a buffing machine fitted with a fine abrasive disc makes surface preparation perfect, especially on parquets with boards laid in a staggered pattern: mosaic, chevron, , Hungary pattern, etc.
- Carefully remove dust using a powerful vacuum cleaner (the surface to be treated as well as the skirting, edges of windows and radiators).

Technical Data Sheet issued on the 6.05.2005. The information provided in this Technical Data Sheet is given in good faith for information purposes only. In no case whatsoever can this information be considered as a guarantee given by us nor engage our responsibility when our products are used. Since we are constantly striving to improve our products, the information given herein may be subject to modification without prior notice. This Technical Data Sheet cancels and supersedes all previous versions.

BLANCHON S.A. - Société anonyme
à directoire et conseil de surveillance
au capital de 4 258 258 €
RCS LYON 390 112 886 - APE 243 Z
CCP 196.03 F LYON

E-mail : info.uk@blanchon.com
Site internet : www.blanchon.com



28, rue Charles Martin - BP 105
69192 SAINT-FONS CEDEX (France)
Tél. 04 72 89 06 00
Fax 04 78 70 07 18

Export Direct Lines
Tél : (0033) 472 89 06 09
Fax : (0033) 472 89 06 02