



General Description

Junckers PROFESSIONAL 625 is a quick-drying, two-component, acid-curing wood- or parquet floor lacquer designed for the professional user.

Junckers PROFESSIONAL 625 provides a hard-wearing lacquer surface.

Compared to similar products **Junckers PROFESSIONAL 625** contains solvents with milder odour and solvency power.

Technical Data

Product:	2-component, acid-curing lacquer. The lacquer and hardener are supplied in 2 separate containers to be mixed before use.
Package sizes:	1 + 0.04 litre, 5 + 0.2 litre, 10 + 0.4 litre.
Appearance:	Colourless.
Gloss:	Matt, Silk or Gloss.
Mixing:	Shake or stir lacquer part well. Mix 25 parts of Junckers PROFESSIONAL 625 Lacquer to 1 part of Junckers PROFESSIONAL Hardener 625 and stir continuously.
Pot-life:	24 hours at 20°C.
Coverage:	10 m ² per litre.
Application tools:	Brush, mohair roller, air/airless spray.
Substrate temperature:	Minimum 5°C.
Dilution:	Junckers PROFESSIONAL 625 and Junckers PROFESSIONAL Hardener 625 are delivered ready for use.
Drying time:	Sanding: 1 hour. Recoating: 1½ hours. Light traffic: 24 hours. Maximum hardness achieved after 72 hours.
Cleaning of tools:	Junckers Thinner 007.
Storage:	Lasts for 2 years if unopened and stored at 20°C.

System Recommendations

- High traffic areas:** 1 coat **Junckers PROFESSIONAL 625 Matt** 10 m²/ltr. *
+ 1 coat **Junckers PROFESSIONAL 625** in needed gloss 10 m²/ltr.
- Domestic and light commercial traffic areas:** 1 coat **Junckers PROFESSIONAL 625** 10 m²/ltr.
+ 1 coat **Junckers PROFESSIONAL 625** in needed gloss 10 m²/ltr.
- Sport areas:** Not recommended.

Note * : A more full-bodied finish is obtained when **Junckers PROFESSIONAL 625** in Matt is used as primer.

Directions for Use

Previously lacquered floors:

Machine sand before applying **Junckers PROFESSIONAL 625**. Machine sand by first using sandpaper grit 24-36 to strip old coats. Then remove abrasion marks using grit 60-80. Finally, use grit 100-120 to obtain a completely smooth surface. Vacuum thoroughly. Shake or stir lacquer part well. Mix lacquer and hardener whilst stirring continuously. Apply a coat of **Junckers PROFESSIONAL 625** and allow drying. Sand with fine paper (grit 150-180) along the fibres of the wood. Vacuum sanding dust and wipe with a well wrung out cloth and clean water. Apply a further coat of **Junckers PROFESSIONAL 625**.

Important!

Before use of the product, read the label on the container carefully and observe the advised precautionary safety measures.

Important!

Stir well before use.

Further information

Products:

F 7.5 - **Junckers Thinner 007**